



Hazards	cuts, lacerations, heavy lifting
Tools/Equipment	table saw, jointer, circular saw, clamps, sander, knife, straight edge
Employee Group(s)	Facilities Management - Carpentry

Required PPE:



Safety Shoes



Eye
Protection



Ear
Protection

SAFE WORK PRACTICES

- Do not perform the procedure or operate the equipment until you have been appropriately trained and authorized to do so by your supervisor.
- Inspect required personal protective equipment (PPE) and replace if required.

PROCEDURE

1. Measure door opening/hinges/lock opening.
2. Scribe door with knife to prevent splintering.
3. Cut down bottom of door with circular saw.
4. Cut the width of door with jointer (two-man job).
5. Place door in vice to router (two-man job).
6. Cut out lock opening using lock jig.
7. Sand all rough edges with sander.
8. Hang door in paint shop.
9. Hang door at site (two-man job).

NOTE: All PPE, tools and equipment shall be used in accordance with provincial OH&S legislation, manufacturer's specifications, applicable standards and codes of practice.